





- 1) 08 8176
(D,I)
08 8722
(GB)
08 8723
N,SF
08 8724
(S,DK)
08 8725
(NL,F)
08 8726
(YU,TR)
08 8727
(E,GB)

Gebrauchsanweisungen:

- 51 3549
(D,I,S,N,SF)
51 3550
(S,DK)
51 3551
(NL,F,E,GB)
Programmtabellen:
51 3552
(D)
51 3553
(I,S,N,SF)
51 3554
(S,DK)
51 3555
(NL,F,E,GB)
Aufstellanweisungen
51 3556
(D,I,S,N,SF)
51 3557
(S,DK)
51 3558
(NL,F,E,GB)



1) 27 1716
15 5272
Triac-Motorleistung

