




51 4896
 Gebrauchsanweisung
 (D)
 514971
 Tips und Rezepte
 (D)


1) 05 3176
 2) 02 1947
 3) 02 5992
 4) 01 8981
 5) 05 1477
 6) 08 3566

Zubehör:

Bratpfanne
 CZ 2010


Backblech-Alu
 CZ 2012


Backblech emailliert
 CZ 2016




1) 02 3799

1) 02 2695







1) 09 5120
Set