




- 2) 08 8174
(D,I)
08 8716
(GB)
08 8717
(N,SF)
08 8718
(S,DK)
08 8719
(NL,F)
08 8720
(YU,TR)
08 8721
(E,GR)
Gebrauchsanweisungen:
51 3549
(D,I,S,N,SF)
51 3550
(S,DK)
51 3551
(NL,F,E,GB)
Programmtabellen:
51 3552
(D)
51 3553
(I,S,N,SF)
51 3554
(S,DK)
51 3555
(NL,F,E,GB)
Aufstellanweisungen:
51 3556
(D,I,S,N,SF)
51 3557
(S,DK)
51 3558
(NL,F,E,GB)
1) 27 3953
Blende kompl.
3) 08 8912
15 5272
Triac-Motorlei-
stung

