






Gebrauchsanweisung
51 4553
(D,NL,F,E,GB,I)

Programmtabellen:
 51 3552
 (D)
 51 3553
 (I,S,N,SF)
 51 3554
 (S,DK)
 51 3555
 (NL,F,E,GB)

Einbauanweisung
51 4554
(D,NL,F,E,GB,I,SF,
S,N,DK)

1) 27 2585
Blende kompl.





- 1) 05 6766
D1
05 8436
D2
- 2) 27 1715
15 5272
Triac-Motorleistung

