




51 4393
Gebrauchsanweisung
(DK,S)

Zubehör:

Einbaurahmen
HZ 67020
kratzfeste Abdeckung
HZ 67720
Alu-Backblech
HZ 8055
Glaspfanne
HZ 8056
Glasbräter
HZ 9150


1) 03 0681
grün

2) 03 0680

3) 03 0679

4) 05 7322

5) 03 0682



- 1) 03 0671
2) 03 0813
Arretierstift

