



Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

52 9650
(de,en,fr,it,nl
el,es,pt,tr)

58 0519
(da,no,sv,fi
ro,hu,pl,ru)


- 1) 17 2762
- 2) 17 2579
- 3) 18 8197




Mat. - Nr. - Konstante
3740

- 1) 17 2274
- 2) 06 0115
- 3) 06 0083
- 4) 18 8194
- 5) 18 8188

Mat. – Nr. – Konstante
3740





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor	ASPERA		
Typ/Type/Tipo	NBU 1118Y		
Förderleistung/Delivery/Debit/Aspiración l/h			
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A	–		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	13.6		
Hi/aux.	14.7		
Klape Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión		kalt	warm
Schaltwerte/Switching values/	..ein/conex.°C		
Valeurs de commutation/Desconex.	..aus"/descon.		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R600	g	45	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	150	
Heizung/Heater/Chauflage/Resistenc.descong.		Verdampfer	
Widerstand/Resistance/Resistencia	KΩ	0.375	
Leistung/Power/Puissance/Potencia	W	145/230V	
Ventilator/Blower/Ventilateur/Ventilador		Verdichter	
Widerstand/Resistance/Resistencia		KF 0.57	Verdampfer
			GF 0.47

Mat. – Nr. – Konstante
3740

1) 06 0182