


**BOSCH**WFK5000-WFK5000/06-D1
WFK5000-WFK5000FG/06-FG1WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740

- 1) 27 7717
Blende kompl.
- 2) 08 8738
(D,I)
08 8734
(NL,F)
08 8735
(S,DK)
08 8736
(E,GB)
08 8737
(SF,N)
- 3) 08 8912
15 5272
Triac-Motorleistung

Gebrauchsanweisungen:


- 51 3566
(D,I,S,N,SF)
51 3567
(S,DK)
51 3568
(NL,F,E,GB)


Programmtabellen:

- 51 3552
(D)
51 3553
(I,S,N,SF)
51 3554
(S,DK)
51 3555
(NL,F,E,GB)


Aufstellanweisungen:

- 51 3556
(D,I,S,N,SF)
51 3557
(S,DK)
51 3558
(NL,F,E,GB)

**BOSCH**WFK5000-WFK5000/06-D1
WFK5000-WFK5000FG/06-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740

**BOSCH**WFK5000-WFK5000/06-D1
WFK5000-WFK5000FG/06-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740

1) 05 8436

**BOSCH**WFK5000-WFK5000/06-D1
WFK5000-WFK5000FG/06-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740