



Gebrauchsanweisung
51 3747
(D,GB,F,I,NL,N)
Montageanweisung
51 2737
(D,GB,F,I,NL,DK,N,S,SF,E)
Schraubensatz
08 4136
Befestigungssatz
08 6512

1) 02 9480





TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES			
Verdichter/Compressor/Compresseur	Danfoss		
Typ/Type	TLES 6 K		
Förderleistung/Delivery/Débit	l/h	1026	
Anlaufstrom/Starting current/Cour de démarrage	A	4,0	
Widerstand/Resistance/Résistance	Ha/main/prin.	Ω	18,9
	Hi/aux	Ω	15,3
Temp.-Regler/Thermostat			
Typ/Type			
Reglerstellung/Position			
Schaltwerte/Switching values/Valeurs de commutation	„ein“ „aus“ („abtauen“ od.)	°C	
Füllmenge/Fill.quantity/Charge	R600a	g	*
Anschlußwert/Conn.load/Puiss. connectée	W	120	
Heizung/Heater/Chauffage			
Widerstand/Resistance/Résistance	Ω		
Leistung/Power/Puissance	W		
Ventilator/Blower/Ventilateur			
Widerstand/Resistance/Résistance	Ω		
Schaltuhr/Timer/Minuterie de contact			
Widerstand/Resistance/Résistance	Ω		
Magnetventil/Magnetic valve/Electrovanne			
Widerstand/Resistance/Résistance	Ω		
Spannung/Voltage/Tension	V		

* siehe Typenschild

Pos.	V01	V02	
	Danfoss	Matsushita	
	TLES 6 K	SD 65 E	
1	14 1306	14 1316	
2			
3	15 1055	03 2035	
4			
5	15 0760		
6	15 1072	05 8458	
7			
8	27 8207	27 1375	
9	05 0166	05 0166	
10			
11	08 4744	08 8893	
12	05 6008	05 6008	