





Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
58 3744
(da,sv,no,fi)
V01
58 4274
(da,sv,no,fi)
V02

Montageanweisung:
52 4904
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)


Zubehoer:
HEZ1004
Backblech Alu
HEZ1100
Backblech emailliert
HEZ1300
Universalpfanne
HEZ1400
Kombirost
HEZ2400
Einlegerost
HEZ1710
Teleskopauszug
3-fach
HEZ1711
Teleskopauszug
Vollauszug
HEZ1712
Teleskopauszug
2-fach





Mat. – Nr. – Konstante
3740


1) 48 2981
Set

Zubehoer:
HEZ1700
Profi-Auszug
HEZ4701
Deckel f. Profipfanne
HEZ2500
Grillblech
HMZ21GB
Glasbraeter
HEZ6000
Metallbraeter
HEZ5072
Tuergriff Alu
HEZ6001
Backform
Auslaufsicher
HEZ1610
Katalyse-Set





Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740

