



Electrolux

SPARE PARTS LIST
Wash and dryer machines
(Household)
2530


Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EWV12853	TWN

SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.


When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.

Electrolux Thailand Co.,Ltd. 1910 Electrolux Building New Petchburi Rd. Bangkapi Huaykwang Bangkok , 10310 Tel : +662 725 9000		Publication-No. 171003	Wash and dryer machines (Household)
--	--	---------------------------	---




Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EWV12853	TWN

Pos.	Part No.	Description
13	110825803	DOOR SAFETY BUTTON
260	124067303	SPRING
300	147912111	PANEL FRONT HEC STD WHITE
300A	132608795	CABINET ASSY,HEC54,PCM,WHT
300B	132763805	PANEL,BACK,HIGH
303A	147904400	DOOR FILTER
308	147910701	PORTHOLE HINGE
312	132764000	PORTHOLE GLASS
323	147909205	REAR PORTHOLE FRAME SS
323A	147909310	OUTER RING, SILVER
323B	147909125	FRONT PORTHOLE FRAME
323C	147909502	DOOR LENS
328B	132782755	C.AQUA CONTROL G50
330	132500704	ASSEMBLY,FOOT,BUSH,20
330C	110877100	NUT,PLASTIC
514	807493801	BUSHING HINGE
523D	132502201	HINGE REINFORCEMENT
530A	147909410	PORTHOLE HANDLE SILVER PAINTED
530B	132554110	CATCHER PIN ICON
530C	124013721	DOOR LATCH
530D	132829001	DOOR LATCH SPRING
530E	132829100	PORT HOLE HANDLE SPRING
552B	132734201	SUPPORT,HOSE DRAIN,HIGH
552C	132736704	SUPPORT,DRWIN HOSE,LOW
563	132554120	DOOR HING PIN
563E	132476800	CLIP,ASSEMBLY CLIP WITH LOCK
586L	132782500	BRACKET SHOCK ABSORBER SX G50
586L	132782601	BRACKET SHOCK ABSORBER DX G50
586C	147909900	METAL PIVOT BRACKET



Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EW12853	TWN

Pos.	Part No.	Description
106	124947005	VALVE 3 CONNECTION
109	124624641	CONVEYOR SET
110	147765410	INTERNAL DRAIN ASSY, G50 OKO
110C	807202001	INLET DETERG.HOSE WD G50
111P	147154935	SOLENOID VALVE+HOSE CLAMP ASSY
111Q	147154936	SOLENOID VALVE+HOSE CLAMP ASSY
111R	147154937	SOLENOID VALVE+HOSE CLAMP ASSY
111	A03184101	INLET HOSE ASSEMBLY (COLD)
112A	808276401	EXTERNAL DRAIN HOSE ASSY
140	132640481	DETERGENT,HOUSING,SHORT
145	132766640	PUMP BODY ASSEMBLY OKO
148	124624241	COVER SYPHON 3C 209
148A	132756000	DRAWER PARTITION RIB L.D.
251B	132501401	BUFFER,UPPER,PUMP BODY
307	147171211	DRAWER (NCS 3000N)
338	124291600	END PIECE DRAIN HOSE



Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EWX12853	TWN

Pos.	Part No.	Description
4	A01846403	MOTOR AL PM MP
5	132518844	VALVE INLET 3-WAY WITH FLOW 3%
6	147112331	PUMP-ASSY DRAIN CU 60HZ RD OR
7	132846904	DOOR LOCK INSTANT SECUR+
10	132724241	HEATER-ASSY 3W1900T 1950W-230V
11	132667300	ANTINOISE-FILTER FL SAPPHIRE
012A	132819502	SENSOR PRESSURE ST-545 0-380MM
019D	129719603	CABLEDUCT,POWERCABLE
531C	124022201	MOTOR SCREW(5,5X38TE)
550	A00109303	DOOR LOCK PROTECTION
550A	132117605	DRAIN PUMP PROTECTION
587	97391490068600	Config PCBA MB EWX14 WD POTTING For PNC 914900686 ELC 00
587A	192651589	PCBA UI TC5 WD-EUI12200STARSAP
587B	A03592701	PCBA MOTOR CONTROL EMC14 PMM
587D	807453302	PCBA AUX SELECTOR-TC4-EAX12300
990	807484701	EMERGENCY DOOR LOCK STRIP
991	A03854602	HARNESS-ASSY MAIN,G50XC OKO WD
999	A03684401	POWERCORD FL TAIWAN


A03533613

Non Config Board

PCBA MB EWX14 WD POTTING IND


Ex. View Drawing

FUNCTION ASSEMBLY




Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EW12853	TWN

Pos.	Part No.	Description
115	132724647	PORTH.GASKET WM TRAD.P10
125	132562100	SPRING,BELLOW,TUB,G33 ICON
125A	132556200	BELLOWS CLAMP WITH SPRING
150	132810722	BACK TUB SHELL G50D25
151	132762394	ASSY SPIDER-BUSHING
152	132816700	GASKET PROBE WD
153	132827400	PROBE SUPPORT WD G60
154	807165801	THERMOSTAT NTC WD 93JB TOD
155	132763000	HEATING ELEMENT SPRING
255A	132774910	BALL BEARING 25X52X15
255B	132774900	BALL BEARING 20X47X14
130X	124056600	SEALING RING
150A	132792620	FRONT TUB SHELL G50 AP
150B	A00255913	DRUM ASSEMBLY, G50XC W25
251B	132255383	SHOCK ABSORBER ASSY
253	A06314101	POLI-V BELT
257A	132768844	COUNTERWEIG.ASSY G50 WD 25MM
260	132768413	TUB SPRING G50
262	A02164602	LIFTER,G50XC, LEAN, S-SHAPE
264	132396554	PULLEY (G50)
156	124001400	PLAIN WASHER,WHEEL
157	522308049	WASHER
158	124021912	PULLEY SCREW
531D	132658901	FRONT COUNTERWEIGHT SCREW
563	132780412	SHOCK ABSORBER PIN
N.I	147100700	TUB SHELL GASKET G23




Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EWV12853	TWN

Pos.	Part No.	Description
313	147772121	WORK TOP ASSEMBLY
509	147915301	KNOB TC4 SILVER
505A	147913420	LED DIFFUSOR SUPPORT TC4
507	A03875344	ASSY CONTROL FRAME,EVV12853 EN
523	132552808	CONTROL BRACKET
523A	132658301	SUPPORT,WG SPRING
523B	132658310	SUPPORT,WG SPRING



Item	PNC	ELC	Brand	Model	Market
A	914900686	00	Electrolux	EWV12853	TWN


Pos.	Part No.	Description
3	A00188001	THERMOSTAT 1 SHOT 36FXE14 TOO
3B	A00189501	THERMOSTAT AUTO 36TXE11 TOD
4A	A02775602	MOTOR FAN, SHADED POLE, CU, WD
10	808040801	HEATER ASSY,3I100R,1000W-230V
18	132819100	FAN WD G60
48	807487301	THERMOSTAT NTC AIR 279 ELTH
125	549012009	THERMOSTAT O-RING 14X1.78
130A	808848403	AIR DUCT GASKET G50 WD
130B	132816902	GASKET O-RING 94.9 X 3.2
130E	124088402	GASKET THERMOSTAT EWW1292
135A	807267202	UPPER AIR DUCT
135B	807267303	LOWER AIR DUCT
540A	132824900	PIPE DOOR GASK,CLIP WDP10



SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove ANY detachable parts while the machine is powered. The reason is internal faults may cause shorts to components that are normally at low voltage presenting a shock hazard.



SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove ANY detachable parts while the machine is powered. The reason is internal faults may cause shorts to components that are normally at low voltage presenting a shock hazard.