



50 9506
EU1,EU2,CH1,CH2,
NL1
Gebrauchsanweisung
(D,F,GB,NL,I,SF)





Pos.	EU1,EU2, CH1,CH2,NL1		
1	14 0124		
2	02 1627		
3	02 1577		
4	05 1276		
5			
6	02 1746		
7	02 1747		
8	11 1493		
9	05 0166		
10			
11	07 5162		
12	02 1562		
13	04 1568		
14			

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Necchi			
Typ/Type		M 3,5 J			
Förderleistung/Delivery/Débit	l/h	630			
Anlaufstrom/Starting current/Cour. de démarrage	A	6,3			
Widerstand/Resistance/Résistance	Ha/main/prin. Ω	30,6			
	Hi/aux Ω	49,0			
Temp.-Regler/Thermostat		M + J			
Typ/Type		TF 57			
Reglerstellung/Position		kalt warm			
Schaltwerte/Switching values/	„ein“ $^{\circ}\text{C}$	+ 4 + 4			
Valeurs de commutation	„aus“	- 24 - 10			
	(„abtauen“ od.) „alarm“				
Füllmenge/Fill.quantity/Charge	R12 g	85			
Anschlußwert/Conn.load/Puiss. connectée	W	90			
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance	Ω				
Leistung/Power/Puissance	W				
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance	Ω				
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance	Ω				
Spannung/Voltage/Tension	V				