





51 0208/00
 Bed.-Anleitung

Kabelsatz
 01 9223/03



TECHNISCHE DATEN / TECHNICAL DATA / DONNÉES TECHNIQUES

Verdichter/Compressor/Compresseur		Aspera			
Typ/Type		A 1111 A			
Förderleistung/Delivery/Débit		l/h	1062		
Anlaufstrom/Starting current/Cour. de démarrage		A	9,0		
Widerstand/Resistance/Résistance		Ha/main/prin.	Ω	17,4	
		Hi/aux	Ω	52,0	
Temp.-Regler/Thermostat		Ranco			
Typ/Type		A 59			
Reglerstellung/Position		kalt	warm		
Schaltwerte/Switching values/ Valeurs de commutation		„ein“	°C	+ 4	+ 4
		„aus“		29	20
		{„abtauen“ od.}	„alarm“		
Füllmenge/Fill quantity/Charge		R12	g	125	
Anschlußwert/Conn. load/Puiss. connectée		W	120		
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance		Ω	3280		
Leistung/Power/Puissance		W	14,8		
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance		Ω			
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance		Ω			
Spannung/Voltage/Tension		V			

Pos.	D1 - D4			
	Aspera			
1	13 1063/45			
2	01 9842/16			
3	07 5586/16			
4	04 0055/05			
5				
6	04 9959/03			
7	01 9846/01/2			
8	11 1838/03			
9	05 0166/05/4			
10				
11	12 3802/01			
12				
13				
14				