


**BOSCH**

BOSCH T 455 – 0 728 144 109–D1
– 0 728 144 110–GB1
– 0 728 144 111–CH1,DK1,S1

WASCHGERÄTE
Trockner

Ident-Nummern-Konstante
3740



Aufstellanweisungen:

51 1191
(D,GB,F,I,NL)
51 1366
(D,F,I,S,DK)

Gebrauchsanweisungen:

51 1182
(D,GB,F,I,NL)
51 1679
(D,F,I,S,DK)




BOSCH

BOSCH T 455 -- 0 728 144 109-D1
-- 0 728 144 110-GB1
-- 0 728 144 111-CH1,DK1,S1

WASCHGERÄTE
Trockner

Ident-Nummern-Konstante
3740



**BOSCH**

BOSCH T 455 — 0 728 144 109—D1
— 0 728 144 110—GB1
— 0 728 144 111—CH1,DK1,S1

WASCHGERÄTE
Trockner

Ident-Nummern-Konstante
3740

