






0199



0195





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor				
Typ/Type/Tipo	JIAXIPERA			
Förderleistung/Delivery/Debit/Aspiración l/h	NT1113Y			
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A				
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm				
Hi/aux.				
Klappe Therm./Thermostat/Termostat				
Typ/Type/Tipo				
Reglerstellung/Position/Conexión				
Schaltwerte/Switching values/	..ein/conex.°C			
Valeurs de commutation/Desconex.	..aus"/descon.			
(..abtaven' od)	..alarm'			
Füllmenge/Fill. quantily/Charge/Carga R600	g	96		
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W			
Heizung/Heater/Chauflage/Resistenc.descong.				
Widerstand/Resistance/Resistencia	KW			
Leistung/Power/Puissance/Potencia	W			
Ventilador/Blower/Ventilateur/Ventilador				
Widerstand/Resistance/Resistencia	KW			
† Siehe Typenschild/Mamul etiketine bakiniz				