





Gebrauchsanweisung
52 2708
(de,en,fr,it,nl)

Montageanleitung
58 8057Beistellsatz
26 5162

Temp.-Regler
Rep.-Satz
26 5271



	V01		
	Danfoss		
Pos.	TLY7KK2		
1	14 2059		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7	16 9319		
8	26 4879		
9	05 0166		
10	16 5852		
11			
12			

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES			
Verdichter/Compressor/Compresseur		Danfoss	
Typ/Type		TLY7KK2	
Förderleistung/Delivery/Débit	l/h	1168	
Anlaufstrom/Starting current/Cour de démarrage	A	5,7	
Widerstand/Resistance/Résistance	W	27,1	
Hi/aux	W	27,2	
Temp.-Regler/Thermostat		KER	
Typ/Type		RCO	
Regelstellung/Position		kalt	warm
Schaltwerte/Switching values	ein"	-23,0	-15,0
Valeurs de commutation	aus"	-31,0	-21,0
Füllmenge/Fill.quantity/Charge		R600a	*
Anschlußwert/Conn.load/Puiss. connectée	W	71	
Heizung/Heater/Chauffage			
Widerstand/Resistance/Résistance	W		
Leistung/Power/Puissance	W		
Ventilator/Blower/Ventilateur			
Widerstand/Resistance/Résistance	W		
Temp.-Regler/Thermostat			
Magnetventil/Magnetic valve/Electrovanne			
Widerstand/Resistance/Résistance	W		
Spannung/Voltage/Tension	V		

* siehe Typenschild