


**BOSCH**

HMG8561FB/01-V01, graphitschwarz
 HMG8561NL/01-V02, graphitschwarz
 HMG8561FB/02-V03, graphitschwarz
 HMG8561NL/02-V03, graphitschwarz

HERDE
 Mikrowellenherde



Mat. - Nr. - Konstante
 3740

Gebrauchsanweisung
 52 0103
 (D,F,GB,I,NL,E)

Programmtabelle
 51 7579
 (D,GB,F,I,NL,E)

Kochbuch
 51 5858
 (F)
 V01,V03
 51 5859
 (NL)
 V01,V02,V04

Zubehör:

Einbaurahmen
 HMZ8162
 Alu-Backblech
 HMZ19BB
 Glaspfanne
 HMZ10GP
 Glasbräter
 HMZ21GB
 Abdeckplatte
 HMZ8760




BOSCH

HMG8561FB/01-V01, graphitschwarz
HMG8561NL/01-V02, graphitschwarz
HMG8561FB/02-V03, graphitschwarz
HMG8561NL/02-V03, graphitschwarz

HERDE
Mikrowellenherde


Mat. – Nr. – Konstante
3740



**BOSCH**

HMG8561FB/01-V01, graphitschwarz
 HMG8561NL/01-V02, graphitschwarz
 HMG8561FB/02-V03, graphitschwarz
 HMG8561NL/02-V03, graphitschwarz

HERDE
 Mikrowellenherde



Mat. - Nr. - Konstante
 3740

- 1) 11 4537
 Glaspfanne
- 2) 11 4539
- 4) 03 2778
- 5) 27 1244
- 6) 27 0323

02 8732
 Anschlag-Backblech

**BOSCH**

HMG8561FB/01-V01, graphitschwarz
HMG8561NL/01-V02, graphitschwarz
HMG8561FB/02-V03, graphitschwarz
HMG8561NL/02-V03, graphitschwarz

HERDE
Mikrowellenherde

Mat. - Nr. - Konstante
3740

