




Gebrauchsanweisung

52 0046

(D,NL,F,RUS,GR,GB)

V01,V04

52 0422-(DK)

V02,V05

52 0423

(N,S,FIN)

V03,V06

Bratautomatikscheibe

51 8365

V01,V04

52 0384

V02,V03,V05,V06

Kochbuch

51 6453-(DE)

V01,V04

Zubehör:

Backblech-Email

HEZ4100

Kombipfanne

HEZ4300

Backblech-Auszug

BACKSHEET
HFZ4200

HEZ4200
Kombirost

HF74400

FEZ4400
Grillblech

Grillblech
HE72500

HEZ2500
Glasbräter

Glasbrater
HM721GB

HMZ21GB
Zweistreckel

Zusatzsockel
UF 35060

HEZ5062
1) 00 00 10

1) 02 0943

2) 15 1483


3) 06 9236

Set


4) 26 5846


Set


5) 01 4254



1) Befestigungssatz
06 9488







- 1) 16 3067
2) 29 7206
Set

