




51 4893  
**Gebrauchsanweisung**  
(D,GB,F,NL,I,E)

51 2001  
**Tips und Rezepte**  
(D)

51 2726  
**Montageanweisung**  
(D,GB,F,NL,I,E)

1) 02 4343  
A1,A4  
01 8981  
A2,A3

**Zubehör:**

**Grillpfanne**  
Z1220X0

**Alu-Backblech**  
Z1320X0


**Back- und  
Bratrost**  
Z1420X0

**Teleskopschiene**  
Z1721X0

**Bratenblech**  
Z1510X0

**Drehspiess-Set**  
Z1162X0

**Brotbackstein**  
Z1910X0



- 1) 05 3112
- 2) 05 4679
- 3) 05 4676
- 4) 02 7966
- 5) Düsensätze für  
Stadtgas  
02 1936  
Erdgas  
02 1937  
Flüssiggas  
05 2418
- 6) 08 4725
- 7) 08 4731
- 8) 08 4732

#### Zubehör

Anschlußgarnitur (FL)  
Z2300X0  
Düsenatz Flüssiggas  
Z2232X0  
Düsenatz Erdgas  
Z2222X0  
Düsenatz Stadtgas  
Z2212X0  
Gasschlauch  
Z2500X1

