




51 5107
Gebrauchsanweisung
(D)

51 4969
Tips und Rezepte
(D)


- 1) 05 3176
- 2) 02 1947
- 3) 02 5992
- 4) 01 8981
- 5) 05 1477
- 6) 08 3566

Zubehör:


Alu-Backblech
CZ 2012



Email-Backblech
CZ 2016


Bratpfanne
CZ 2010



1) 02 2695







1) 09 5120
Set