





Gebrauchsanweisung
 52 3330
 (de,fr,nl,it)


Montageanleitung
 51 7991
 (de,fr,nl,it)

1) 02 5876


Zubehör:

Back- u. Bratrost-
 engmasching
 Z1440X0
 Back- u. Bratrost
 geköpft
 Z1430X0
 Backblech Alu
 Z1330X0
 Backblech Email
 Z1340X0
 Universalpfanne u.
 Bratrost
 Z1230X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
 V01, V03
 16 7262
 V02



1) 15 4779