





Gebrauchs-montage
anweisung
51 9363
(D)


Tips und Rezepte
51 8368
(D)

Zubehör:

Grillpfanne u. Bratrost
Z1230X0

1) 02 5876





- 1) 15 4762
- 2) 15 4763
- 3) 15 4794
- V01
- 15 4764
- V02, V03
- 4) 02 6593

29 6344
V01
29 7052
V02
29 6343
V03

29 7575
V01
29 7577
V02
29 7581
V03

